

Impactools Index

(Alpha order / Numerical order by first letter / Digit of model)

MODEL	DESCRIPTION	PAGE	MODEL	DESCRIPTION	PAGE	MODEL	DESCRIPTION	PAGE
1702P1	3/8" CLASS IMPACTOOL	5	2908P1	3/4" CLASS IMPACTOOL	10	2950A7	1 1/2" CLASS IMPACTOOL	14
1702P4	3/8" CLASS IMPACTOOL	5	2908P2	3/4" CLASS IMPACTOOL	10	2950B1	1 1/2" CLASS IMPACTOOL	14
1702SB1	3/8" CLASS IMPACTOOL	5	2920B1	3/4" CLASS IMPACTOOL	10	2950B7	1 1/2" CLASS IMPACTOOL	14
1712B2	1" CLASS IMPACTOOL	12	2920B3	3/4" CLASS IMPACTOOL (1")	10	588A1	2 1/2" CLASS IMPACTOOL	15
1712P2	1" CLASS IMPACTOOL	12	2920B9	3/4" CLASS IMPACTOOL	10	599A1	3 1/2" CLASS IMPACTOOL	15
1720B1	3/4" CLASS IMPACTOOL	10	2925P1	3/4" CLASS IMPACTOOL	10	5020TAH1	TORQUE CONTROL IMPACTOOL	19
1720B3	3/4" CLASS IMPACTOOL (1")	10	2925P3	3/4" CLASS IMPACTOOL	10	5020TAL1	TORQUE CONTROL IMPACTOOL	19
1720P1	3/4" CLASS IMPACTOOL	10	2925RBP1	3/4" CLASS IMPACTOOL	10	5020TDQ	TORQUE CONTROL IMPACTOOL	19
1720P3	3/4" CLASS IMPACTOOL (1")	10	2925RBP3	3/4" CLASS IMPACTOOL	10	5040TAH1	TORQUE CONTROL IMPACTOOL	19
1734A1	1" CLASS IMPACTOOL	12	2934A2	1" CLASS IMPACTOOL	12	5040TAL1	TORQUE CONTROL IMPACTOOL	19
2131P	1/2" CLASS IMPACTOOL	6	2934B1	1" CLASS IMPACTOOL	12	5040TAM1	TORQUE CONTROL IMPACTOOL	19
2131P7	1/2" CLASS IMPACTOOL (7/16")	6	2934B2	1" CLASS IMPACTOOL	12	5040TDQ	TORQUE CONTROL IMPACTOOL	19
2161P	3/4" CLASS IMPACTOOL	10	2934B9	1" CLASS IMPACTOOL	12	5980A1	1 1/2" CLASS IMPACTOOL	14
2171P	3/4" CLASS IMPACTOOL	10	2934P2	1" CLASS IMPACTOOL	12	5982A1	2 1/2" CLASS IMPACTOOL	15
2705A1	1/2" CLASS IMPACTOOL	6	2940A1	1" CLASS IMPACTOOL	13	8005	ELECTRIC IMPACTOOL	22
2707A1	1/2" CLASS IMPACTOOL	6	2940A2	1" CLASS IMPACTOOL	13	8049	ELECTRIC IMPACTOOL	22
2902P1	3/8" CLASS IMPACTOOL	5	2940B1	1" CLASS IMPACTOOL	13	8053	ELECTRIC IMPACTOOL	22
2903P1	1/2" CLASS IMPACTOOL	6	2940B2	1" CLASS IMPACTOOL	13	8053QC	ELECTRIC IMPACTOOL	22
2903P2	3/8" CLASS IMPACTOOL	5	2940P2	1" CLASS IMPACTOOL	13	8055	ELECTRIC IMPACTOOL	22
2904P1	3/8" CLASS IMPACTOOL	5	2945A7	1 1/2" CLASS IMPACTOOL	14	8056	ELECTRIC IMPACTOOL	22
2904P2	1/2" CLASS IMPACTOOL	6	2945B1	1 1/2" CLASS IMPACTOOL	14	8062	ELECTRIC IMPACTOOL	22
2906P1	1/2" CLASS IMPACTOOL	6	2945B7	1 1/2" CLASS IMPACTOOL	14			

Contact Information

United States

Marketing/Sales/Service Headquarters

Ingersoll-Rand Tool and Hoist Division
1467 Rte. 31 South
Annandale, NJ 08801
Telephone: (908) 238-7000
Fax: (908) 238-7052

Distribution Center

Ingersoll-Rand Tool and Hoist Division
510 Hester Drive
White House, TN 37188
Telephone: (615) 672-0321
Fax: (615) 672-0801

Central Regional Office

Ingersoll-Rand Tool and Hoist Division
131 W. Diversey Avenue
Elmhurst, IL 60126-1102
Telephone: (630) 530-3873
Fax: (630) 530-3891

Detroit/Metro Regional Office

Ingersoll-Rand Tool and Hoist Division
1872 Enterprise Drive
Rochester Hills, MI 48309
Telephone: (248) 293-5700
Fax: (248) 293-5807

Eastern Regional Office

Ingersoll-Rand Tool and Hoist Division
900 East 8th Avenue, Suite 103
King of Prussia, PA 19406
Telephone: (610) 337-5930
Fax: (610) 337-5912

Southern Regional Office

Ingersoll-Rand Tool and Hoist Division
450 Gears Road, Suite 210
Houston, TX 77067-4516
Telephone: (281) 872-6800
Fax: (281) 872-6807

Western Regional Office

Ingersoll-Rand Tool and Hoist Division
13107 Lakeland Road
Santa Fe Springs, CA 90670
Telephone: (562) 777-0808
Fax: (562) 777-0818

Canada

Marketing/Sales/Service Headquarters

Ingersoll-Rand Canada Inc.
51 Worcester Road
Toronto, Ontario M9W 4K2
Telephone: (416) 213-4500
Fax: (416) 213-4510

Alberta

Ingersoll-Rand Canada Inc.
9720-54 Avenue
Edmonton, Alberta T6E 0A9
Telephone: (780) 438-5039
Fax: (780) 430-4500

Quebec

Ingersoll-Rand Canada Inc.
3501 St. Charles Blvd. Suite 104
Kirkland, Quebec H9H 4S3
Telephone: (514) 695-9040
Fax: (514) 695-0963

British Columbia

Ingersoll-Rand Canada Inc.
1200 Cliveden Ave.
Delta, B.C. V3M 6G4
Telephone: (604) 523-0803
Fax: (604) 523-0801

Latin America

Marketing/Sales/Service Headquarters

Ingersoll-Rand Company
730 N.W. 107th Ave. Suite 300
Miami, FL 33172-3107
Telephone: (305) 559-0500
Fax: (305) 222-0864

Brasil

Ingersoll-Rand do Brasil Ltda.
Tool & Hoist Division
Av. Dr. Cardoso de Melo 1855
cj. 152-04548-005 Sao Paulo., SP
Brasil
Telephone: (55) 11 3049-8900
Fax: (55) 113846-4985

Chile

Ingersoll-Rand Chile
Nueva Tajamar 555, 15th fl.
Las Condes, Santiago
Chile
Telephone: (56) 2 339-7939
Fax: (56) 2 339-7940

Mexico

Ingersoll-Rand S.A. de C.V.
Tool & Hoist Division
Blvd. Centro Industrial #11
Fracc. Industrial Puente de Vigas, 54090
Tlanepilantla, Edo. de Mexico, Mexico
Telephone: (52) 5 565-3061
Fax: (52) 5 565-3072

Europe/Middle East/Africa

Tool & Hoist Division Headquarters and

European Customer Care Centre

Ingersoll-Rand
Zone du Chêne Sorcier
BP 62
78346 Les Clayes sous Bois Cedex
France
Telephone: +33 (0)1 30 07 68 00
Fax: +33 (0)1 30 07 69 80

Ingersoll-Rand Distribution Centre

Swan Lane
Hindley Green
Wigan
Lancashire WN2 4EZ
England
Phone: +44 (0)1942 257131
Fax: +44 (0)1942 526255

Asia/Pacific

Marketing/Sales/Service Headquarters

Ingersoll-Rand Asia Pacific
23/F., 625 Kings Point Road
North Point
Hong Kong
Phone: (852) 2527 -0183
Fax: (852) 2529 -5976

Australia

Ingersoll-Rand Australia, Ltd.
1 Hartnett Drive
Mail: PMB 2, Carrum Downs BC, Vic., 3201
Seaford, Victoria 3198
Australia
Phone: (61) 3 9554 1600
Fax: (61) 3 9554 1611

India

Ingersoll-Rand Wadco Tools, Ltd.
37A, Site 4
Sahibabad Industrial Area
Ghaziabad 201 010 (UP)
Phone: (91) 0120-4771-001-4
Fax: (91) 0120-4771-005

For additional specific information on Ingersoll-Rand locations in Europe and Asia, visit our website at: www.irtools.com.

Disclaimer: Nothing contained within this brochure is intended to extend any warranty or representation, expressed or implied, regarding the products described herein. Any such warranties or other terms or conditions of the sale of products shall be in accordance with Ingersoll-Rand Standard Terms and Conditions of Sale for such products which are available upon request.

Product improvement is a continuing goal at Ingersoll-Rand. Designs and specifications are subject to change without notice or obligation.



Ingersoll-Rand Company
Tool and Hoist Division
1467 Route 31 South
Annandale, New Jersey 08801
www.irttools.com